



Spray backside with protective paint after soldering

- GND ○ X1C
- W237-3F ○ X1B
- L ○ X1A

Sheet: /		
File: Power_Distribution_V1.1.kicad_sch		
Title:		
Size: User	Date:	Rev:
KiCad E.D.A. 9.0.0		Id: 1/1