



They will periodically be set to
INPUT_PULLDOWN and read so the RP2040
knows which position the switch is in

Probe Button and Probe Probe will
swap roles when in Disconnect mode

(Routable Buffer will keep it high)



Sheet: /
File: V5probe.kicad_sch

Title:

Size: A4
KiCad E.D.A. 9.0.0

Date:

Rev:
Id: 1/1