

Connectors

Battery Terminal

V_BAT_IND 1 J1
GND-G 2 Screw_TerminalL01x02

5V Terminal

3 outputs in total

5V_OUT_1D 1 J4
GND-D 2 Screw_TerminalL01x06
5V_OUT_2D 3
GND-D 4
5V_OUT_3D 5
GND-D 6

