

X3	
Цепь	Контакты
red	3
red	4
red	9
red	10
orange1	1
orange2	2
orange3	7
orange4	8
brown	5
brown	6
brown	11
brown	12

X1	
Цепь	Контакты
MISO	1
VCC	2
SCK	3
MOSI	4
RST	5
GND	6

X2	
Цепь	Контакты
PWR	1
GND	2

X4	
Цепь	Контакты
SDA	1a
SDA-PWR	1b
SCL	2a
SCL-PWR	2b
GND	3a
PWR	3b
PWR	4a
GND	4b

X5	
Контакты	Цепь
3	red
4	red
9	red
10	red
1	orange1
2	orange2
7	orange3
8	orange4
5	brown
6	brown
11	brown
12	brown

