



WARNING: +5V is +5P; GND is GNDPWR and so is the BNC shield.

Ondřej Sluka	
Sheet: /	
File: vetrnik-current-sensor-opamp.kicad_sch	
Title: vetrnik-current-sensor-opamp	
Size: A4	Date:
KiCad E.D.A. 9.0.0	Rev: Id: 1/1