



These are through hole fuse clips. A ceramic fuse connects these to contacts.
 USB 2.0 ports are rated at 500mA so a 400mA fuse is recommended here.

In some situations (namely, integration testing), we want the bus to be powered without having the radio board connected.
 By moving a jumper on these pins, you can power the bus from the USB port of your computer.

It is also often a pain to wire up an external CAN bus resistor, this jumper makes it internal.

Sheet: /	
File: usbdbg.kicad_sch	
Title: USB debug respin	
Size: A4	Date: 2023-11-25
KiCad E.D.A. 9.0.0	Rev: 1/1